

## **Incus GDU-01-TT**

### Ultrasonic Test Transmitter



## Important instructions

Emerson designs, manufactures, and tests products to function within specific conditions. Because these products are sophisticated technical instruments, it is important that the owner and operation personnel strictly adhere both to the information printed on the product nameplate and to all instructions provided in this manual prior to installation, operation, and maintenance.

### **⚠ WARNING**

Installing, operating, or maintaining an Emerson product improperly could lead to serious injury or death from explosion or exposure to dangerous substances.

Comply with all information on the product, in this manual, and in any local and national codes that apply to the product.

Do not allow untrained personnel to work with this product.

Use Emerson parts and work procedures specified in this manual.

Authorized personnel for installing, operating, servicing, and maintaining the GDU-01-TT are instructed and trained qualified personnel of the operating company and the manufacturer.

It is the operating company's responsibility to:

- Train staff.
- Observe safety regulations.
- Follow the Reference Manual.

Operators must:

- Have been trained.
- Have read and understood all relevant sections of the Reference Manual before commencing work.
- Know the safety mechanisms and regulations.

To avoid personal injury and loss of property, do not install, operate, maintain, or service this instrument before reading and understanding this reference manual and receiving appropriate training.

### **⚠ WARNING**

#### **Physical access**

Unauthorized personnel may potentially cause significant damage to and/or misconfiguration of end users' equipment. This could be intentional or unintentional and needs to be protected against.

Physical security is an important part of any security program and fundamental to protecting your system. Restrict physical access by unauthorized personnel to protect end users' assets. This is true for all systems used within the facility.

## NOTICE

The contents of this publication are presented for informational purposes only and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, expressed or implied, regarding the products or services described herein or their use or applicability. All sales are governed by Emerson's terms and conditions, which are available upon request. We reserve the right to modify or improve the designs or specifications of such products at any time. Emerson does not assume responsibility for the selection, use, or maintenance of any product. Responsibility for proper selection, use, and maintenance of any Emerson product(s) remains solely with the purchaser and end user.

To the best of Emerson's knowledge, the information herein is complete and accurate. Emerson makes no warranties, expressed or implied, including implied warranties of merchantability and fitness for a particular purpose with respect to this manual and, in no event, shall Emerson be liable for any incidental, punitive, special, or consequential damages including, but not limited to, loss of production, loss of profits, loss or revenue, or use and costs incurred including without limitation for capital, fuel and power, and claims of third parties.

Product names used herein are for manufacturer or supplier identification only and may be trademarks or registered trademarks of these companies.

All rights reserved. No part of this work may be reproduced or copied in any form or by any means graphic, electronic, or mechanical without first receiving written permission of Emerson, Shakopee, Minnesota, United States.

## Warranty

1. **Limited Warranty:** Subject to the limitations contained in Section 2 (Limitation of Remedy and Liability) herein, Seller warrants that (a) the licensed firmware embodied in the Goods will execute the programming instructions provided by Seller; (b) that the Goods manufactured by Seller will be free from defects in materials or workmanship under normal use and care; and (c) Services will be performed by trained personnel using proper equipment and instrumentation for the particular Service provided. The foregoing warranties will apply until the expiration of the applicable warranty period. Products purchased by Seller from a third party for resale to Buyer (Resale Products) shall carry only the warranty extended by the original manufacturer. Buyer agrees that Seller has no liability for Resale Products beyond making a reasonable commercial effort to arrange for procurement and shipping of the Resale Products. If Buyer discovers any warranty defects and notifies Seller thereof in writing during the applicable warranty period, Seller shall, at its option, (i) correct any errors that are found by Seller in the firmware or Services; (ii) repair or replace FOB point of manufacture that portion of the Goods found by Seller to be defective; or (iii) refund the purchase price of the defective portion of the Goods/Services. All replacements or repairs necessitated by inadequate maintenance; normal wear and usage; unsuitable power sources or environmental conditions; accident; misuse; improper installation; modification; repair; use of unauthorized replacement parts; storage or handling; or any other cause not the fault of Seller, are not covered by this limited warranty and shall be replaced or repaired at Buyer's sole expense and Seller shall not be obligated to pay any costs or charges incurred by Buyer or any other party except as may be agreed upon in writing in advance by Seller. All costs of dismantling, re-installation, freight and the time and expenses of Seller's personnel and representatives for site travel and diagnosis under this limited warranty clause shall be borne by Buyer unless accepted in writing by Seller. Goods repaired and parts replaced by Seller during the warranty period shall be in warranty for the remainder of the original warranty period or 90 days, whichever is longer. This limited warranty is the only warranty made by Seller and can be amended only in a writing signed by an authorized representative of Seller. The limited warranty herein ceases to be effective if Buyer fails to operate and use the Goods sold hereunder in a safe and reasonable manner and in accordance with any written instructions from the manufacturers.

THE WARRANTIES AND REMEDIES SET FORTH ABOVE ARE EXCLUSIVE. THERE ARE NO REPRESENTATIONS OR WARRANTIES OF ANY KIND, EXPRESSED OR IMPLIED, AS TO MERCHANTABILITY, FITNESS FOR PARTICULAR PURPOSE OR ANY OTHER MATTER WITH RESPECT TO ANY OF THE GOODS OR SERVICES.

- 2. Limitation of Remedy and Liability: SELLER SHALL NOT BE LIABLE FOR DAMAGES CAUSED BY DELAY IN PERFORMANCE. THE REMEDIES OF BUYER SET FORTH IN THE AGREEMENT ARE EXCLUSIVE. IN NO EVENT, REGARDLESS OF THE FORM OF THE CLAIM OR CAUSE OF ACTION (WHETHER BASED IN CONTRACT, INFRINGEMENT, NEGLIGENCE, STRICT LIABILITY, OTHER TORT OR OTHERWISE), SHALL SELLER'S LIABILITY TO BUYER AND/OR BUYER'S CUSTOMERS EXCEED THE PRICE TO BUYER OF THE SPECIFIC GOODS MANUFACTURED OR SERVICES PROVIDED BY SELLER GIVING RISE TO THE CLAIM OR CAUSE OF ACTION. BUYER AGREES THAT IN NO EVENT SHALL SELLER'S LIABILITY TO BUYER AND/OR BUYER'S CUSTOMERS EXTEND TO INCLUDE INCIDENTAL, CONSEQUENTIAL OR PUNITIVE DAMAGES. THE TERM "CONSEQUENTIAL DAMAGES" SHALL INCLUDE, BUT NOT BE LIMITED TO, LOSS OF ANTICIPATED PROFITS, REVENUE OR USE AND COSTS INCURRED INCLUDING WITHOUT LIMITATION FOR CAPITAL, FUEL AND POWER, AND CLAIMS OF BUYER'S CUSTOMERS.

**Contents**

Introduction..... 5

Safety guidelines..... 6

Unpack and inspect..... 7

Operation..... 8

Troubleshooting..... 14

Specifications..... 15

Accessories..... 17

Service support..... 19

# 1 Introduction

## 1.1 Product overview

Emerson has designed the GDU-01-TT Ultrasonic Test Transmitter to electrically replace the airborne ultrasound generated from a pressurized gas leak using a piezoelectric disc. You can use the GDU-01-TT to activate alarm conditions with any ultrasonic gas leak detector.

When gas moves from a high-pressure area to a low-pressure area, it generates airborne ultrasound. The ultrasonic sound level depends on three main factors:

- Pressure drop across leak
- Size of leak (area)
- Specific gas properties (molecular weight and specific gas ratio)

The GDU-01-TT is constructed from 316 stainless steel mounting hardware and a semi-crystalline polyphenylene sulfide (PPS) enclosure. The transmitter is battery-operated and is intended to be activated within close proximity of an ultrasonic detector. When activated, the transmitter helps to confirm that the ultrasonic detector is operating correctly.

The transmitter's effective range, due to the nature of the electronically produced ultrasound, is 8m. The range may be reduced based on the level of background ultrasound being generated in close proximity to the ultrasonic detector that the GDU-01-TT is activating.

## 1.2 Product recycling/disposal

Consider recycling equipment and packaging. Dispose of the product and packaging in accordance with local and national legislations and regulations.

## 2 Safety guidelines

### **⚠ WARNING**

#### **Use in hazardous areas**

The GDU-01-TT is not hazardous area certified.

Only use the GDU-01-TT in accordance with site specific safety guidelines for non-certified equipment.

### **⚠ CAUTION**

Only use the GDU-01-TT with Emerson approved accessories and charging equipment.

#### **Important**

All liability for the correct function of the GDU-01-TT is irrevocably transferred to the owner/operator if the GDU-01-TT is altered incorrectly by personnel not authorized by Emerson or if the GDU-01-TT is used in non-conformance to its intended use.

## 3 Unpack and inspect

### Procedure

1. Carefully remove all components from the packaging.
2. Verify the components against the enclosed packing list.
3. Inspect all components for obvious damage, such as broken or loose parts.
4. If any components are missing or damaged, contact your local Emerson representative or the factory immediately.

Store the transmitter in a covered, dry, clean, and safe environment. Ensure that the storage temperature is between -20 °C and 75 °C and that relative humidity does not exceed 95 percent non-condensing. Periodically inspect the stored box to ensure no tampering or deterioration has occurred.

## 4 Operation

The key for correct operation of the GDU-01-TT Ultrasonic Test Transmitter is in the relationship between the ultrasonic transmitter and ultrasonic detector.

Due to the nature of electronically emitted ultrasonic waves for optimal performance, it is very important to have the transmitter aligned perpendicular ( $\pm 2.5^\circ$ ) to the decibel sensing face. The closer the GDU-01-TT is to the detector, the higher the detector's decibel output.

The GDU-01-TT has no adjustable controls and is set up to produce approximately 106 dB at 1 meter in single operation mode.

### **⚠ CAUTION**

**The test transmitter is not intended to output a precise sound pressure level (SPL).**

Do not attempt to calibrate ultrasound detectors using this equipment.


---




## 4.1 User interface

---

**Figure 4-1: Test Transmitter Interface**



- A. **Activation** button
  - B. **Battery Low** indicator
  - C. **Activation** indicator
  - D. Charge socket
  - E. **Battery Charge** indicator
  - F. **Battery Charge** indicator **On/Off** button
  - G. **Mains Connected** indicator
  - H. **On/Off** indicator
-

**Figure 4-2: GDU-01-TT Ultrasonic Emitter Location***A. Ultrasonic emitter***⚠ CAUTION**

Always cover the ultrasonic emitter with the cap provided when not in use.

## 4.2 Operate

### Prerequisites

Ensure that the GDU-01-TT is fully charged before use. Refer to [Charge the battery](#) for charging instructions.

## Procedure

1. Check the battery charge by pushing the battery charge indicator button.

See [Figure 4-2](#).

During normal operation, the **On/Off** indicator will be illuminated and the battery low indicator will be off.

---

### Note

If the **Battery Low** indicator is illuminated, Emerson recommends charging the GDU-01-TT before use.

---

2. Remove the transmitter cap located on the ultrasonic emitter (see [Figure 4-2](#)) and aim the GDU-01-TT at the ultrasonic detector.

To achieve best results see [Verifying alarm settings](#) through [Activating a time delayed alarm](#).

3. Press and hold the **Activation** button to transmit an ultrasound emission.  
During normal operation, the activation indicator will illuminate to show ultrasound emission. If the activation indicator is off at any time while the button is pressed, the results are invalid.

## Postrequisites

Once you have finished testing the detector, Emerson recommends replacing the transmitter cap.

## 4.3 Verifying alarm settings

Determine the ultrasonic detector alarm settings before using the GDU-01-TT for operational verification.

The operator will need to determine the distance, or range, between the GDU-01-TT and the ultrasonic detector based on the ultrasonic detector's alarm level. In general, the higher the alarm level setting, the shorter you need to make the distance between the detector and the GDU-01-TT.

## 4.4 Activating a time delayed alarm

For alarm verification, determine the detector alarm delay before using the GDU-01-TT.


Activate the transmitter using the **Activation** button for a time longer than the delay and ensure that the activation indicator is illuminated for the specified time. Emerson recommends turning off the alarm delay during the test. Ensure the time delay is reinstated after testing to prevent unwanted alarms.

### 4.5 Operating range and alignment angle

The GDU-01-TT can electronically transmit ultrasonic waves over a long distance. However, it typically has a narrow field of response when used in conjunction with an ultrasonic detector due to the nature of electronically emitted sound.

Figure 4-3 shows the recommended angular alignment of the GDU-01-TT to the sensor face for maximum output.

**Figure 4-3: Operating Distance and Angular Alignment**



*A. Detector sensor face*

You can effectively use the GDU-01-TT at a range of up to 8 m, but take ultrasonic background noise into account before using the GDU-01-TT to verify detector operation. A higher ultrasonic background noise will reduce the GDU-01-TT's effective range.

### 4.6 Using accessories

Emerson recommends attaching the shoulder strap to the GDU-01-TT with the fastening clips before using it.

## 4.7 Charge the battery

If the **Battery Low** indicator illuminates when you turn on the GDU-01-TT, Emerson recommends fully charging it before use.

### Procedure

Plug the charger into the charging socket (orientation tab ensures correct polarity) and charge for eight hours to ensure the full charge cycle.

The mains connector illuminates to show power is connected, and the battery charge indicator will illuminate to show the charge cycle has begun.

When the battery charge indicator goes off, the charge cycle is complete.

## 5 Troubleshooting

The GDU-01-TT cannot be repaired in the field.

In the event of a GDU-01-TT failure (i.e., user interface indicators failing to light, charging problems, or loss of ultrasound emission), please consult your Emerson representative.

### **Related information**

[Service support](#)

# A Specifications

<b>Frequency range(s)</b>	40 kHz ( $\pm 1$ kHz)
<b>Dimensions</b>	245 mm x 180 mm x 130 mm
<b>Weight</b>	4 kg
<b>Enclosure material</b>	Semi-crystalline modified polyphenylene sulfide and AISI 316 stainless steel transmitter mounting
<b>Operating temperature</b>	-20 °C to 75 °C
<b>Storage temperature</b>	-20 °C to 75 °C
<b>Humidity</b>	0 to 95% relative humidity (RH) non condensing





## B Accessories

Part number	Description
GDU-01-TT-CHARGER	Spare 18 V standard charger for GDU-01-TT



## C Service support

For technical support, contact your Emerson representative or email [safety.csc@emerson.com](mailto:safety.csc@emerson.com).

The Response Center will ask for product model and serial numbers and will provide a Return Material Authorization (RMA) number.

The Response Center will also ask for the installation and application details.

---

### **Note**

Ship all equipment prepaid. Emerson will not accept collect shipments.

---



**Quick Start Guide**  
**00825-0300-3003, Rev. AB**  
**August 2022**

For more information: [\*\*Emerson.com\*\*](https://www.emerson.com)

©2022 Emerson. All rights reserved.

The Emerson logo is a trademark and service mark of Emerson Electric Co. All other marks are the property of their respective owners.

